

Part of R4

SW2

Red
9V
Black


CW Key

Rear view
of switch
(solder lugs)
CW position
(center)
shown

Piezo
Sounder

Black
Red

Telex 610
600 Ohm Headphones



Phone jack

Rear view RCA jack


R14 is standing on end
with TP1 on top

FOR BASIC-2

C1 is 1 capacitor, 0.68uf
C8 is 3.3uf
All other parts are installed.

FOR BASIC-1

C1 is 2 capacitors, .027uf each
C8 is 4.7uf
D6, R15-17, U2 and socket
are not installed.
D6 and R15 are replaced by jumper wires.



PC BOARD PARTS LAYOUT AND FRONT PANEL WIRING